


**GROUND LOOP NOISE ISOLATOR
USER MANUAL**



Connection Instructions:
Connect GROUND LOOP NOISE ISOLATOR
between speaker and Bluetooth receiver
with dual 3.5mm audio cable or 3.5mm to
RCA audio cable as the following
Picture shows.

Note: It can use from both sides, no
direction limited, just plug one jack as input,
The other is output.



**Completely eliminating the buzzing noise caused by
ground loops which happens when the audio source
and the speaker use the power source**